

# Zero Volt Bench Top Ionizer Installation, Operation, and Maintenance Instructions



Figure 1. 62204 Zero Volt Bench Top Ionizer

## Installation

Remove the ionizer from the carton and inspect for damage. Included with the unit should be:

1. Emitter cleaner
2. Power Cord (62204 Only), 220V Power Cord sold separately
3. Certificate of Calibration

The input voltage should be set to your specification prior to shipping. It can be verified or reset by referring to the **Maintenance** section of these instructions.

Attach the stand to the unit by placing the plastic spacers between the unit and the stand and securing in place using the knurled knobs. If desired, attach rubber feet to each corner of the bottom of the stand. Press feet firmly in place.

Before installing the unit, verify that the AC outlet is properly connected to earth ground. The unit must have a good earth ground to maintain proper balance.

Install the unit in the desired location, making sure that the airflow will not be restricted. Be sure the ON/OFF switch, located on the rear of the unit, is in the "OFF" position. Plug the power cord into the unit and then into the appropriate AC power source. This equipment has a grounding type plug that has a third (grounding) pin. This plug will only fit into a grounding type power outlet. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet. Do not alter the plug in any way.

Status of the unit can be monitored remotely via the RS485 data ports. Please contact the factory for the necessary polling utility software.

## Operation

Set the fan speed switch on the rear of the unit to the LOW, MED, or HI position. Higher airflow will result in faster neutralization rates. Position the unit so that the maximum airflow is directed at the items or area to be neutralized. Turn the unit ON.

When the unit is first turned on, it conducts a self-test. The audible alarm will sound and then the LED will cycle through RED, YELLOW, and then GREEN. The LED will remain GREEN during normal operation.

## Balance Adjustment

The 62204 / 62210 (ZVI5100) is an auto-balancing unit. However, tuning or manual adjustment can be accomplished by inserting a small screwdriver or trimmer adjustment tool into the balance adjustment hole located on the right rear of the unit. To increase the output in a positive direction, turn the potentiometer in a clockwise direction. Conversely, to increase the output in a negative direction, turn the potentiometer in a counter clockwise direction.

## Maintenance / Alarms

**WARNING - RISK OF ELECTRIC SHOCK** - These servicing instructions are for use by qualified personnel only. To reduce the risk of electric shock, do not perform any servicing of internal parts unless you are qualified to do so.

The input voltage may be verified or reset by removing the back case by disengaging the 3 screws on back. **NOTE:** The AC power cord **MUST** always be disconnected before the unit is disassembled.

Input voltage is selected with the two internal jumpers as shown below:




Figure 2. 110 Volt Jumper Setting




Figure 3. 220 Volt Jumper Setting

If the supply voltage drops from 110 Volts to below 85 Volts or from 200 Volts to below 170 Volts, the unit will shut down the audible alarm will beep and the LED will blink RED. The unit will automatically reset when the minimum voltage is restored.

Under normal conditions, the ionizer will attract dirt and dust (especially on the emitter electrodes). To maintain optimum neutralization efficiency and operation, cleaning should be performed on a regular basis.

In the event of circuit failure, the unit will enter shutdown mode.

When the unit enters shutdown mode, ionization will be stopped, the LED on the front of the unit will change to a steady of RED, and the audible alarm will sound continuously. If the ionizer enters shutdown mode, it must be turned OFF and then back ON to reset the unit.

**NOTE:** The AC power cord **MUST** be disconnected before the unit is disassembled for maintenance. The emitter electrodes should be cleaned using the alcohol cleaners included or a swab wet with Isopropyl alcohol. First, turn the unit OFF and unplug the power cord. Then remove the rear screen by disengaging the 4 screws on back. After cleaning the emitter electrodes, reattach the rear screen using the 4 screws. Plug in the power cord and turn the unit back ON.

The emitter electrodes should not require replacement during the life of the unit with normal handling. Replacement emitter electrodes can be ordered if necessary.

Best practice would be to verify the balance of the unit with a charge plate monitor after cleaning.

## Specifications

- Air Flow  
Three speed fan (125fpm -250fpm; 50-100cfm).
- Balance  
±3 volt, typical; ±5 volts maximum.  
(Temperature range: 65oF to 80oF, R.H.: 15% to 65%)
- Chassis  
White powder coated aluminum housing.
- Dimensions ( with stand )  
9.5: high x 6.0" wide x 3.1" deep.
- Emitter Points  
.050" diameter pure tungsten for improved mechanical strength and ionization stability.
- Fuse  
250 mA slow blow.
- High Voltage Power Supply  
5.5 kV DC nominal.
- Input Power  
AC line power, internally selectable for 110/115 VAC-50/60Hz or 220/230 VAC-50/60Hz.
- Ion Emission  
Steady state DC with sense feedback.
- Mounting  
Bench top tilt adjust frame.
- Ozone  
Less than 0.05ppm
- Weight  
4.5 pounds

**NOTE:** Unauthorized servicing or modifications to your ionizer will void the product warranty and may create dangerous conditions. Servicing should be performed only at the factory, or by a Semtronics approved technician.

## Neutralization (Decay) Times

The comparative efficiency of benchtop ionizers is determined by a standard test published by the ESD Association: Standard S3.1. Typical positive and negative decay times (from 1000 volts to 100 volts) measured using this standard are shown below. The performance of the ionizer was measured with the unit positioned as shown, with the fan speed on high, and without a filter.

0"		12"		24"		36"		48"		12"
		+101s -125s		+18s -23s		+13s -17s		+19s -23s		
Ionizer		+2s -2s		+4s -5s		+7s -9s		+13s -15s		Center Line
		+23s -36s		+14s -15s		+15s -16s		+21s -22s		12"

## Contact and Warranty

ESD Systems  
432 Northboro Road Central  
Marlboro, MA 01752  
Tel: (508) 485-7390  
Fax: (508) 480-0257

**NOTE:** Unauthorized servicing or modifications to your monitor will void the product warranty and may create dangerous conditions. Servicing should be performed only at the factory, or by a Semtronics approved technician.

### LIMITED WARRANTY

ESD Systems expressly warrants that for a period of one (1) year from the date of purchase, the ESD Systems Footwear Tester will be free of defects in material (parts) and workmanship (labor). Within the warranty period, a unit will be tested, repaired, or replaced at our option, free of charge. Call Customer Service at 909-627-8178 (Chino, CA) or 781-821-8370 (Canton, MA) for Return Material Authorization (RMA) and proper shipping instructions and address. Include a copy of your original packing slip, invoice, or other proof of date of purchase. Any unit under warranty should be shipped prepaid to the Semtronics factory. Warranty replacements will take approximately two weeks. If your unit is out of warranty, ESD Systems will quote repair charges necessary to bring your unit up to factory standards. Call Customer Service at 909-627-8178 for proper shipping instructions and address. Ship your unit freight prepaid.

### WARRANTY EXCLUSIONS

THE FOREGOING EXPRESS WARRANTY IS MADE IN LIEU OF ALL OTHER PRODUCT WARRANTIES, EXPRESSED AND IMPLIED, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH ARE SPECIFICALLY DISCLAIMED. The express warranty will not apply to defects or damage due to accidents, neglect, misuse, alterations, operator error, or failure to properly maintain, clean or repair products.

### LIMIT OF LIABILITY

In no event will ESD Systems or any seller be responsible or liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, users shall determine the suitability of the product for their intended use, and users assume all risk and liability whatsoever in connection therewith.