



PROPER INSTALLATION OF FULL COVERAGE FOOT GROUNDERS

Insert the conductive grounding tab (B) inside the shoe and under the foot. Pull front (C) and side (D) extension tabs securing Full Coverage Foot Grounder around the periphery of shoe positioning strips (A) under heel and ball of foot. Then, tuck excess conductive grounding tab (B) into side of shoe.



Test each foot grounder on an ESD footwear tester to confirm proper installation.

Charleswater

Unit 17, Millbrook Business Park, Sybron Way, Crowborough, East Sussex, TN6 3JZ, U.K.

• Phone: 00 44 (0) 1892-665313 • Fax: 00 44 (0) 1892-668838 • E-mail: info@charleswater.co.uk • Internet: www.charleswater.co.uk